




FINESTA ELECTRIQUE















20min

FINESTA ELECTRIQUE




FINESTA ELECTRIQUE

NO.	DESCRIPTION	QTY	NO.	DESCRIPTION	QTY
①		1	⑥		1
②		1	⑦		1
③		1	⑧		1
④		4	⑨		2
⑤		1			


NO.	DESCRIPTION	SPEC	QTY
A		M4×10	8PCS
B		M4	2PCS
C		M4	2PCS

FINESTA ELECTRIQUE



1



2




FINESTA ELECTRIQUE



FINESTA ELECTRIQUE

5



ATTENTION ! Ne pas fermer le couvercle pendant l'utilisation.
WARNING ! Do not close the lid during use.
¡ATENCIÓN ! No cierre la tapa durante el uso.
ATENÇÃO ! Não feche a tampa durante o uso.
ATTENZIONE ! Non chiudere il coperchio durante l'uso.
ACHTUNG ! Schließen Sie den Deckel nicht während des Gebrauchs.
LET OP ! Sluit het deksel niet tijdens gebruik